Upgrading Recorder Firmware from USB

Copyright

© 2017, Lorex Corporation

All rights reserved worldwide. Names and marks appearing herein are either registered trademarks or trademarks of Lorex Corporation and/or its subsidiaries. All other trademarks, trade names or company names referenced herein are used for identification only and are the property of their respective owners.

Document identity

Publ. No.: LX400090
Commit: 43895
Head: 43895
Language: en-US
Modified: 2017-07-21
Formatted: 2017-07-21

Website

www.lorextechnology.com

Legal disclaimer

As our product is subject to continuous improvement, Lorex Corporation & subsidiaries reserve the right to modify product design, specifications & prices without notice and without incurring any obligation. E&OE.

1 Upgrading Firmware from USB

Download and install the latest firmware for your DVR or NVR system to improve device security. This firmware upgrade can be done by downloading the firmware file to your computer, then copying it to a USB drive.

To upgrade firmware from a USB drive on an LHV / LNR Series recorder:

1. Download the firmware upgrade for your DVR or NVR from the **Downloads** section of your recorder's product page on www.lorextechnology.com.
2. Copy the **.bin** firmware file to a blank USB drive.

> **NOTE**
>
> Ensure that there are no folders on the USB drive – just the firmware file. It is recommended to format the USB drive before copying the firmware file onto it.

3. Insert the USB drive into a USB port on the recorder.
4. The **USB Detect** screen appears. Click **System Upgrade**.

> **NOTE**
>
> If prompted, enter the username and password for your recorder. If your system is still using the default username (**admin**) and password (**000000**), it is strongly recommended that you change your login credentials.

5. Click **Upgrade**.

© 2017, Lorex Corporation.
#LX400090; r. 43895/43895; en-US

6. The contents of the connected USB drive are displayed. Select the firmware file, then click **Start**.

⚠ **WARNING**
DO NOT POWER OFF THE SYSTEM OR DISCONNECT THE POWER CABLE DURING FIRMWARE INSTALLATION.

The system automatically restarts to complete the firmware upgrade process.