Copyright

© 2015, FLIR Systems, Inc.

All rights reserved worldwide. Names and marks appearing herein are either registered trademarks or trademarks of FLIR Systems and/or its subsidiaries. All other trademarks, trade names or company names referenced herein are used for identification only and are the property of their respective owners.

Document identity

Publ. No.: LX400054
Commit: 22635
Head: 22635
Language: en-US
Modified: 2015-01-19
Formatted: 2015-01-19

Website

www.flirsecurity.com/pro

Technical Support

1-866-816-5919

Customer Service

1-866-344-4674

Legal disclaimer

Specifications subject to change without further notice. Camera models and accessories subject to regional market considerations. License procedures may apply. Products described herein may be subject to US Export Regulations. Please refer to exportquestions@flir.com with any questions.

1 DNR100 / DNR200 Series Firmware Upgrade Instructions

To update the system firmware:

1. Download the latest firmware update from www.flirsecurity.com/pro. Extract the firmware file and copy to a blank USB flash drive (not included).

NOTE
Do not have any folders on the USB flash drive—just the firmware file.

2. Connect the USB flash drive to a USB port on the NVR.
3. Right-click and then select **Main Menu>Info>Version**. Enter the system user name (default: **admin**) and password (default: **000000**) to log in.

4. Click **Start** to update firmware. Wait for the firmware upgrade to complete.

CAUTION
Do not remove the USB flash drive until the upgrade process is complete or power off the NVR during the upgrade process.