# Lorex Client 11

Lorex Client 11 is a software for the PC that allows you to control, and manage multiple DVRs. Lorex Client 11 allows you to view, search, and backup video from your system remotely.

#### **Minimum System Requirements**


- Pentium® 4 or above
- Windows XP/Vista/7
- 256 MB RAM or greater
- 16 MB of video memory
- LAN) 10/100 BaseT Network

## **Prerequisites**

- Set up your system for DDNS access.
- •
- Port forward the required Client Port to your router.

## **Installing Lorex Client 11**

- 1 Download and install the Lorex Client 11 software on the Lorex Website (www.lorexcctv.com), under your DVRs' product page.
- 2 Double-click the installation file ( 50), and follow the on-screen instructions.




3 Double-click the Lorex Client 11 icon ( ) to launch the software.


## **Adding your DVR to Lorex Client 11**

## To add you DVR to Lorex Client 11:

1 Click **Config**. The configuration window opens.



2 Click Add.



- 3 Configure the following:
  - Device: Enter the desired DVR name.
  - Client Port: Enter the DVR's client port (default, port 9000)
  - **User name:** Enter the DVR's user name (default, admin)
  - Device IP: Enter the DVR's DDNS address or local IP address.

**NOTE:** Enter your DDNS address without "http://". For example, enter: tomsmith.lorexddns.net.

- Password: The default password for the client is 000000.
- Auto Login: Select Enable or Disable.




4 Click **OK** to save your settings.

# **Connect to your DVR**

Once you configure you DVR settings in the Software Client, your DVR populates in the left column.

### To connect to your DVR:

1 Right-click on your DVR, and click **Login**.



2 Right-click on your DVR, and click Open All Channels.




**3** Click the grid icons to view up to 16 channels simultaneously.



# **Searching for Video**

## To search for video:


1 Click Playback.




2 Drag the channels that you wish to search, into the quad screen.




3 In the Calendar, select the desired month and date you wish to search for video. Click **Search**.



4 The search time line populates with a green bar.



5 Click the channel that you wish to begin playback, then click the play button ( ). Video playback begins on the selected channel only. Repeat the process for the remaining channels.



**NOTE:** You can view up to 4 channels at once.

# **Timeline Tips**

• Click in the desired area of the timeline to jump forward or backward in the video.



## Taking a Screen Shot

You can take a screen shot of the channel. The image saves into the default save directory (C:\Program Files\Lorex Client 11\Capture).

To take a screen capture of a channel:

1 Click the icon on the desired channel. The image saves to the default directory.



# **Recording Video**

To capture video onto the hard drive:

1 Click the icon to start recording. Click again to stop recording.




**NOTE:** The default video save directory is: C:\Program Files\Lorex Client 11\Download\RecordFile.


# Configuring the system settings

## To configure the system menu:

1 Right-click on the name of your DVR on the left-handed column. Click **Device Parameters**.



2 Configure the system settings as required. Note that the menu structure is similar to the local and remote viewing.



# **Changing the Save directory**

To change the default save directory:


- 1 Click the Config tab→ Path Parameters.
- **2** Configure the following:
  - Download Path: Select the save directory for recorded video.
  - Image Capture: Select the save directory for screen captures.



# **Adding new users**

To add new users to the DVR:

- 1 Click the Config tab→User Parameters.
- 2 Click Add.



3 Enter the new user name and password. Click **OK** to save your settings.



4 Select the desired menus the user will have access to. Click **0K** to save your settings.

