

**1** Connect the power adapter to the camera(s). Connect the other end to a power outlet.

**2** Turn on the camera(s).

**3** Connect the cradle to your router using an Ethernet cable (included).

**NOTE:** Ensure the switch on the back is set to INTERNET mode. DIRECT mode is for service use only. Disconnect and reconnect the power adapter after changing to INTERNET mode.

**4** Connect the cradle power adapter to the cradle. Connect the other end to a power outlet.

**5** Installing the monitor's battery:

**a**

Use a Phillips screwdriver (not included) to open the battery compartment on the back panel.

**b**

Connect the battery cable to the terminals in the monitor.

**!** The battery cable only connects one way. Do not force the battery cable.

**c**

Uncover the adhesive strips on the battery to secure it in the compartment.

When finished, close the battery compartment and replace the screws.

**\*NOTE:** If you do not plan to use the unit for a prolonged period of time, disconnect the battery or ensure you charge it at least once every 6 months.

**6** Place the monitor onto the power/network connector on the cradle.

**The monitor will charge when connected to the cradle.**  
It takes 5 hours to fully charge the monitor.

**7** Download the free **Lorex Care** app for iOS or Android™ on your smartphone or tablet.

**See reverse to complete setup.**

**ATTENTION**

When someone is connected to the cameras using a smartphone or tablet, recording is stopped and you will not be able to use the buttons or menus on the handheld monitor.

See the WiFi Remote Connection Cradle User Guide for more information.

### iPhone®/iPad® Setup

OR

### Android™ Setup

- 1 Touch the **Lorex Care** icon to launch the app.
- 2 Tap **Add Device** and then **QRCode** to launch the QR code scanner.
- 3 Scan the QR code on the side of the cradle using your device's camera.
- 4 Enter a name for your system and the default password **000000**.
- 5 Tap **Save**.
- 6 Select your device to connect.

The app will connect to your system and stream live video from your cameras.

**NOTE:** If your device does not have a camera, Tap **Add** and manually enter the **UID** printed below the QR code on the side of the cradle.

- 1 Touch the **Lorex Care** icon to launch the app.
- 2 Tap **Click here to add device**.
- 3 Tap **Scan**.
- 4 Scan the QR code on the side of the cradle using your device's camera.
- 5 Enter the default password **000000** and a name for your system. Tap **OK**.
- 6 Select your device to connect.

The app will connect to your system and stream live video from your cameras.

**NOTE:** If your device does not have a camera, Tap **UID** and manually enter the **UID** printed below the QR code on the side of the cradle.

**NOTE:** You may be prompted to select the app that will be used to scan the QR code. Select **Google** and press **Always** to continue.

### iPhone®/iPad® Wi-Fi Setup (Optional)\*

- 1 Open the Device List screen in **Lorex Care**. Press **Back** if you are currently connected to a camera.
- 2 Tap the blue arrow next to the device to connect.
- 3 Tap **Advanced Setting**.
- 4 Tap **WiFi**.
- 5 Select your Wi-Fi network.
- 6 Enter the password for your Wi-Fi network then tap **Join**.
- 7 Press **Back** 3 times to return to the Device List.
- 8 Remove the Ethernet cable from the cradle.
- 9 Select your device to connect.

Congratulations! You have successfully connected the cradle to your Wi-Fi network. You can now place the cradle in any location with good signal to your Wi-Fi network.

### Android™ Wi-Fi Setup (Optional)\*

- 1 Open the Device List screen in **Lorex Care**. Press **Back** if you are currently connected to a camera.
- 2 Tap the blue arrow next to the device to connect.
- 3 Tap **Edit Device**.
- 4 Tap **Advanced**.
- 5 Tap **Manage Wi-Fi networks**.
- 6 Tap here, then select your Wi-Fi network.
- 7 Enter your Wi-Fi network's password. Tap **OK**.
- 8 Tap **OK** twice to return to the Device List.
- 9 Remove the Ethernet cable from the cradle.
- 10 Select your device to connect.

Congratulations! You have successfully connected the cradle to your Wi-Fi network. You can now place the cradle in any location with good signal to your Wi-Fi network.